


This is the top of the pulsar.



**This is the vehicle side of the harness.
Positive wire on top;
Negative wire on bottom.**

**This is the light side of the harness.
Positive wire on top;
Negative wire on bottom.**

The pulsar MUST be installed as per this diagram, if the contacts are not tight and the pulsar is not installed as per above the unit may not work properly.