


GMG R50/R52/R53 Nuvi GPS Bracket Installation Instructions


Tools Rq'd: T25 Torx driver, 7mm wrench, 2mm, 3mm Hex Driver



Step 1: Assemble GPS Ball to GPS Arm

- Insert the M4 x 30 screw into GPS Ball then through the GPS Arm. Using a 3mm Hex wrench and a 7mm wrench, assemble the Flat Washer and M4 Nylock Nut to the back side of the GPS Arm.
- Attach your Nuvi Mount to GPS Ball.

Step 2: Mount Step 1 to Tach Mount



- Determine preferred GPS location
Holes A = Right Side Widescreen Mounting or Left 3.5" Screen Mounting
Holes B = Left Side Widescreen Mounting or Right 3.5" Screen Mounting



- Using 2mm hex driver, attach GPS Arm assembly to Tach bracket with the two M3 x 6 screws.
- This pictures shows a 4.3" Nuvi ready to be mounted on the left (driver's) side.

Step 3: Assemble GPS Mount to MINI

- Lower steering column all the way down for easier access behind tachometer.
- Using a T25 Torx driver, remove two screws holding down the tachometer
- Using a magnet, remove two flat washers under screws – you may want to use the magnet to remove the two MINI screws which usually helps remove washers too.
- Align tachometer and GPS bracket with holes and tighten M5 x 30 screws (T25 Torx driver). Start each screw before fully tightening screws. Alternately tighten each screw about ¼" until each screw is tight. You are screwing into aluminum so maximum torque is ~8 in-lbs. *(Tip – insert M5 x 30 screws into bracket first before aligning bracket to tach. Look through windshield to see if tachometer is aligned with steering column holes.)*



Step 4: Attach Nuvi

- Route Nuvi power cord from power source to Nuvi Mount or Nuvi GPS depending on model.
- Attach your Nuvi GPS to your Nuvi Mount.

You are finished!



Thank you for purchasing the GoMiniGo Nuvi GPS Mount

